

FRAME AND BUMPERS

CONTENTS

page

BUMPERS 1

BUMPERS

INDEX

page

page

REMOVAL AND INSTALLATION

EMERGENCY TOE EYE 1
FRONT BUMPER EXTENSIONS 1

FRONT LICENSE PLATE BRACKET 2
REAR LICENSE PLATE BRACKET 2

REMOVAL AND INSTALLATION

EMERGENCY TOE EYE

REMOVAL

- (1) Remove the emergency toe eye cover.
- (2) Remove the emergency toe eye attaching bolts (Fig. 1).




Fig. 1 Emergency Toe Eye

INSTALLATION

- (1) Perform the removal procedure in reverse order.

FRONT BUMPER EXTENSIONS

REMOVAL

- (1) Remove the front bumper extension attaching screws (Fig. 2).
- (2) Remove the front bumper extension.




Fig. 2 Front Bumper Extension

INSTALLATION

- (1) Perform the removal procedure in reverse order.

REMOVAL AND INSTALLATION (Continued)

FRONT LICENSE PLATE BRACKET

REMOVAL

- (1) Remove the front license plate bracket attaching bolts and bracket (Fig. 3).




Fig. 3 Front License Plate Bracket

INSTALLATION

- (1) Perform the removal procedure in reverse order.

REAR LICENSE PLATE BRACKET

REMOVAL

- (1) Remove the rear license plate bracket attaching screws (Fig. 4).
- (2) Disconnect the license plate lamp electrical connectors.




Fig. 4 Rear License Plate Bracket

INSTALLATION

- (1) Perform the removal procedure in reverse order.